
59744

busbars - B83 - Sepam series 80



Relay application	Busbars	
Range of product	Sepam series 80 Sepam series 80 NPP	
Device short name	B83	
Control and monitoring type	Circuit breaker/contactor control ANSI code: 94/69 (option) Latching/acknowledgement ANSI code: 86 Logic discrimination ANSI code: 68 (option) Switching of groups of settings Annunciation ANSI code: 30 Automatic transfer (AT) (option) Logipam programming (ladder language) (option) Logic equation editor 200 operators	
Metering type	Voltage U'21, U'32, U'13, V'1, V'2, V'3, V'd, V'i and frequency Measured residual current I0, calculated I'0∑ Positive sequence voltage Vd/rotation direction Frequency Calculated active and reactive energy (+/- W.h, +/- VAR.h) Active and reactive energy by pulse counting (+/- W.h, +/- VAR.h) (option) Phase current I1, I2, I3 RMS Demand current IM1, IZ, I3 Peak demand current IM1, IM2, IM3 Measured residual current I'0 Voltage U21, U32, U13, V1, V2, V3 Residual voltage V0 Negative sequence voltage Vi Active power P, P1, P2, P3 Reactive power Q, Q1, Q2, Q3 Apparent power S, S1, S2, S3 Peak demand power PM, QM Power factor Residual voltage V'0	
Network and machine diagnosis type	Datalog (DLG) Unbalance ratio/negative sequence current li Disturbance recording Tripping context Phase fault and earth fault trip counters Harmonic distortion (THD), current and voltage lthd, Uthd Difference in amplitude, frequency and phase of voltages with synchro-check (option) Apparent positive sequence impedance Zd Apparent phase-to-phase impedances Z21, Z32, Z13 Phase displacement	
Switchgear diagnosis type	CT/VT supervision ANSI code: 60FL Trip circuit supervision ANSI code: 74 (option)	

Complementary

Type of measurement	Current Energy Frequency Peak demand power Power (P,Q) Power factor Voltage Voltage (x2)
Protection type	Synchro-check (option) ANSI code: 25 Overvoltage (L-L or L-N) ANSI code: 59 Earth fault/sensitive earth fault ANSI code: 50N/51N Earth fault/sensitive earth fault ANSI code: 50G/51G Negative sequence/unbalance ANSI code: 46 Remanent undervoltage ANSI code: 27R Overfrequency ANSI code: 81H Underfrequency ANSI code: 81L Negative sequence overvoltage ANSI code: 47 Positive sequence undercurrent ANSI code: 27D Undervoltage (L-L or L-N) ANSI code: 27 Breaker failure ANSI code: 50BF Neutral voltage displacement ANSI code: 59N Phase overcurrent ANSI code: 50/51
Communication port protocol	Measurement readout (option) : Modbus Remote control orders (option) : Modbus Remote indication and time tagging of events (option) : Modbus Remote protection setting (option) : Modbus Transfer of disturbance recording data (option) : Modbus
Input output max capacity	42 inputs + 23 outputs
Communication compatibility	Modbus RTU IEC 60870-5-103 DNP3 IEC 61850 Modbus TCPIP IEC 61850 goose message
User machine interface type	Advanced Mimic-based Without Remote